

AVON Garden Arch

List of parts in fixing pack

8 x 60mm Green Screws



1. Firstly slot the sides between the roof section and fix using the screws provided. (Ensure the side panels are facing the correct way to allow the roof to place on)
2. When fixing the uprights in the ground, or setting them in concrete, please remember to make sure the sides are level, making the trellis look straight.

PLEASE NOTE: To minimise twisting and warping all garden furniture products are recommended only be used on firm level ground. Softwood is a natural material, which can twist and split during periods of wet/dry, hot/cold weather. If cracks do appear, it is a natural occurrence and not a fault with the product or material. The best way to treat this is to use a cloth and rub a little PVA wood glue into the crack, once dry sand the area lightly. This will not affect the treatment of the product.