

Premium Bird Table's (Windsor, Henley & Epsom)



List of parts

- 2 x Feet Sections**
- 1 x Post**
- 4 x Feet Braces**
- 1 x Bird House**
- 4 x Bird Table Braces (attached to the house)**

Fixings

- 12 x 60mm Screws**
- 2 x 90mm Screws**
- 1 x 60mm Bolt**
- 1 x Allen Key**

1. Slot the two feet together and screw the feet into the bottom of the post using two 90mm screws. (Pilot holes are in the feet)
2. Fix the four braces onto the feet and post using eight 60mm screws.
3. Remove the small post section from the bird house section by unscrewing each of the four braces.
4. Bolt birdhouse section onto the post using the supplied 60mm screws.
5. Screw bracing into the post using four 60mm screws.

PLEASE NOTE: To minimise twisting and warping all garden furniture products are recommended only be used on firm level ground. Softwood is a natural material, which can twist and split during periods of wet/dry, hot/cold weather. If cracks do appear, it is a natural occurrence and not a fault with the product or material. The best way to treat this is to use a cloth and rub a little PVA wood glue into the crack, once dry sand the area lightly. This will not affect the treatment of the product.