

DEAN Chair (DC)

List of parts in fixings pack

- 12 x 60mm Connecting Bolts**
- 12 x 25mm Connecting Caps**
- 2 x Allen Keys**



When assembling, loosely fix together until fully assembled then tighten all the bolts.

1. Bolt four legs to the two armrests (as shown in the picture) using one 60mm bolt and one 25mm cap for each leg.
2. Using four 60mm bolts & caps, fix one leg set to each side of the seat with the notch in the armrest facing inwards.
3. The seat should now be stood on its feet so the back can be slipped into position and bolted using four 60mm bolts and caps provided.
4. Finally tighten all bolts.



PLEASE NOTE: To minimise twisting and warping all garden furniture products are recommended only be used on firm level ground. Softwood is a natural material, which can twist and split during periods of wet/dry, hot/cold weather. If cracks do appear, it is a natural occurrence and not a fault with the product or material. The best way to treat this is to use a cloth and rub a little PVA wood glue into the crack, once dry sand the area lightly. This will not affect the treatment of the product.