

## DEAN Rectangular Dining Set (DRPT)

### *List of parts in fixing pack*

- 4 x 60mm Connecting Bolts**
- 8 x 60mm Screws**
- 1 x Allen Key**



When assembling, loosely fix together until fully assembled then tighten all the bolts.

1. Place the table top upside down, taking care to protect the top from scratching.
2. Slot the leg sections in at each end of the table, checking that the bolt holes in the table align to the inserts in the leg. Fix leg to the table using 60mm bolts provided.
3. Finally screw the two leg supports to the table legs through pre-drilled holes at each end, using eight 60mm screws.



**PLEASE NOTE:** To minimise twisting and warping all garden furniture products are recommended only be used on firm level ground. Softwood is a natural material, which can twist and split during periods of wet/dry, hot/cold weather. If cracks do appear, it is a natural occurrence and not a fault with the product or material. The best way to treat this is to use a cloth and rub a little PVA wood glue into the crack, once dry sand the area lightly. This will not affect the treatment of the product.