

Windermere Planter Bench (WIN)

List of parts and fixings

2 x Planters
3 x Seat Boards
12 x 70mm Screws



1. Place the planters approximately the length of the seat boards apart.
2. Place the 3 seat boards evenly spaced on the ledges of both planters.
3. Screw the seat boards down into the planter ledges through the pre-drilled holes using the screws provided.

PLEASE NOTE: To minimise twisting and warping all garden furniture products are recommended only be used on firm level ground. Softwood is a natural material, which can twist and split during periods of wet/dry, hot/cold weather. If cracks do appear, it is a natural occurrence and not a fault with the product or material. The best way to treat this is to use a cloth and rub a little PVA wood glue into the crack, once dry sand the area lightly. This will not affect the treatment of the product.